


JAC
PHEV/T9
QUICK
START
GUIDE.





LET'S GO:

The JAC T9 PHEV is loaded with tech & spec!
Let's get you started. Still got a question?

- Chat to your local JAC team
- Head to the glovebox and find your Owners Manual
- Visit www.jac.co.nz/owners-info for video tutorials

DRIVE MODES + 4WD SELECTOR:

The T9 PHEV has three drive modes: NORMAL, ECO & SPORT. Select these using the button to the left of the gear knob by pushing the button upwards.

Going off road? Select 'Off Road Mode' using the button near the gear stick. You can also use the drive modes to select more off road modes including 'crawl'. The front and rear diff locks may also come in handy, you may also find that auto hold (A) next to the handbrake can help when starting off, especially when reversing up hills.

EV MODES

By selecting the 'bolt' icon along the bottom of the touchscreen you can open up your energy management centre. Here you can select the EV/Hybrid modes, see EV consumption, enable V2L and more. Tip: look out for info icons on the screen to learn more as you go.

CHARGING

To get the best efficiency out of your T9 we recommend starting your journey with a full charge. Your PHEV is equipped with both AC and DC charging capabilities - your vehicle comes with a portable charger that you can plug into a standard 'home power point'. You can also charge the PHEV at public charging stations using a CCS2 plug. The charging flap is on the drivers side.

KEEP THAT PIE WARM, OR KEEP THAT CAN OF LIQUID ENERGY COOL...

The JAC T9 has a hot/cool box in the centre console:

1. In the centre console, turn the dial to the open position.
2. Set AC to either hot/cold & select the flow to the 'main body'
3. To speed up the cooling/warming of the box you may wish to close the vents on the cabin to direct most of the air into the box.

Please note that the function isn't designed to 'cook' a pie from cold, but it'll keep it nice & toasty for you!



SAFETY FEATURES:

The T9 ute is kitted out with safety tech, sometimes you may wish to turn these off (they will reset each time the vehicle is started to meet ANCAP requirements).

QUICK TURN OFF:

The T9 has a quick turn off buttons for some of the more common functions (eg driver monitoring and lane keeping):

1. Swipe down on the touchscreen
2. Tap the icon for the function you want to turn off
3. Confirm to turn off the function



To access more driver assistance settings:

1. Press the second icon along the bottom of the touchscreen
2. Select 'Intelligent Driving' from the options
3. Access the setting you'd like to edit or turn on/off
4. Some settings have a three lines menu, if you tap this you can edit these further - eg lower the strength of lane keeping

FUEL

The T9 PHEV uses 91 Petrol - the fuel flap is on the passenger side.

APPLE CAR PLAY/ANDROID AUTO:

To connect, head to the Vehicle Settings > Connections > and select Bluetooth. Once bluetooth is connected follow the prompts on your phone. You can also connect using a cable in the left hand USB plug.



TOWING:

The JAC T9 PHEV has a 3.5T braked, & 750kg un-braked capacity.

The T9 is equipped with a Trailer Mode to adjust the vehicle settings. After connecting your trailer a prompt should automatically show on the touchscreen.

Or, to manually access:


1. Swipe down from the top of the touchscreen
2. Select '**Towing**'





ROADSIDE ASSIST:

In a pickle? - Call **0800 922 522** and select 'Roadside Assistance' for 24/7 support.



Watch our 'How To' videos at www.jac.co.nz/owners-info or scan the QR code

*Please note that specifications are subject to change and these instructions may no longer apply. Please contact the JAC team if you have any questions on this guide.